



## FRONT

### HORWIN EK1




N°	PIÈCE	RÉFÉRENCE
1	Headlamp	HORWIN0202
2	Headlamp upper cover	HORWIN0204
3	Headlamp lower cover	HORWIN0205
4	Display case	HORWIN0206
5	Display case lower cover	HORWIN0207
6	Instrument assembly	HORWIN0208
7	Display placing bracket	HORWIN0209
8	Handle assembly	HORWIN0211
9	Steering handlebar bolt, nut and fastening block	HORWIN0212
10	Handlebar bolt rubber	HORWIN0213
11	Left switch assembly	HORWIN0214
12	Right switch assembly	HORWIN0215
13	Left handle cover black	HORWIN0216
14	Right handle cover black	HORWIN0217
15	Acceleration wire	HORWIN0218
16	Left rearview mirror	HORWIN0219
17	Right rearview mirror	HORWIN0220
18	Insert	HORWIN0306
19	Boss self tapping screw 4mm	HORWIN0203
20	Insert self tapping screw 5 mm	HORWIN0210

# BRAKE




N°	PIÈCE	RÉFÉRENCE
1	Brake assembly	HORWIN0020
2	Rear disc brake assembly	HORWIN0225
3	Brake lever right (levier de frein droit)	HORWIN0223
4	Brake lever left (levier de frein gauche)	HORWIN0224
5	Brake pads front EK1 (plaquettes de frein avant)	HORWIN0017
6	Brake pads rear EK1 (plaquettes de frein arrière)	HORWIN0019

# FRONT SHOCK ABSORBERS




N°	PIÈCE	RÉFÉRENCE
1	Front wheel fender	HORWIN0226
2	Steering main rod	HORWIN0227
3	Steel headset	HORWIN0228
4	Left front shock absorber	HORWIN0230
5	Right front shock absorber	HORWIN0231
6	Rubber foot	HORWIN0026
7	Front side reflector	HORWIN0232
8	Disc brake hose clamp	HORWIN0233

## FRONT WHEEL




N°	PIÈCE	RÉFÉRENCE
1	Front Rim	HORWIN0234
2	Front tyre	HORWIN0235
3	Nipple	HORWIN0241
4	Front axle (including sleeve nut)	HORWIN0237
5	Brake disc	HORWIN0238

## BACK WHEEL




N°	PIÈCE	RÉFÉRENCE
1	Rear tyre	HORWIN0240
2	Nipple	HORWIN0241
3	Rear wheel brake disc	HORWIN0242
4	Rear axle disc brake holder	HORWIN0243
5	Rear axle sleeve left	HORWIN0244
6	Rear axle sleeve right	HORWIN0245

# FRAME




N°	PIÈCE	RÉFÉRENCE
1	Frame assembly	HORWIN0246
2	Master Lock mechanic	HORWIN0247
3	Horn	HORWIN0249
4	Throttle support	HORWIN0251
5	Flasher	HORWIN0253
6	Throttle support controller	HORWIN0254
7	Pedal rail	HORWIN0255
8	Frame web	HORWIN0256
9	Left rear pedal	HORWIN0257
10	Right rear pedal	HORWIN0258
11	Controller bracket	HORWIN0259
12	Cushion lock seat	HORWIN0260
13	Cushion lock cable	HORWIN0261
14	Converter screw	
15	Converter bracket screw	
16	Screw	HORWIN0252

# STAND



N°	PIÈCE	RÉFÉRENCE
1	Main support	HORWIN0262
2	Middle stand bolt and nut	HORWIN0263
3	Main support spring	HORWIN0264
4	Main support rebound shock absorption rubber	HORWIN0265
5	Side support	HORWIN0266
6	Side stand step bolt	HORWIN0267
7	Side support spring	HORWIN0268
8	Side support power switch	HORWIN0269

# TRIM PARTS 1




N°	PIÈCE	RÉFÉRENCE
1	Front Spoiler BLACK	
	Front Spoiler BLUE	HORWIN0024
	Front Spoiler WHITE	
	Front Spoiler ORANGE	
2	Panel decorative cover	HORWIN0271
3	Front turn signal / driving light	HORWIN0272
4	Insert	
5	Front cover bottom BLACK	



<b>N°</b>	<b>PIÈCE</b>	<b>RÉFÉRENCE</b>
	<b>Front cover bottom BLUE</b>	
	<b>Front cover bottom ORANGE</b>	
	<b>Front cover bottom WHITE</b>	HORWIN0273
<b>6</b>	<b>Cowl lower cover</b>	HORWIN0274
<b>7</b>	<b>Front box center connecting strip</b>	HORWIN0275
<b>8</b>	<b>Front storage box</b>	HORWIN0276
<b>9</b>	<b>Toolbox cover bracket</b>	HORWIN0277
<b>10</b>	<b>Toolbox cover</b>	HORWIN0278
<b>11</b>	<b>Toolbox cover lining</b>	HORWIN0279
<b>12</b>	<b>Spring</b>	HORWIN0280
<b>13</b>	<b>Rebound stop</b>	HORWIN0281
<b>14</b>	<b>Axis</b>	HORWIN0282
<b>15</b>	<b>Fixed pressure</b>	HORWIN0283
<b>16</b>	<b>Toolbox box</b>	HORWIN0284
<b>17</b>	<b>USB charging port</b>	HORWIN0285
<b>18</b>	<b>Convertor</b>	HORWIN0286
<b>19</b>	<b>Converter holder</b>	HORWIN0287
<b>20</b>	<b>Lower part of front storage box</b>	HORWIN0288
<b>21</b>	<b>Number cover</b>	HORWIN0289
<b>22</b>	<b>Pedal</b>	HORWIN0290
<b>23</b>	<b>Pedal screw cover</b>	HORWIN0291
<b>24</b>	<b>Hook assembly</b>	HORWIN0292
<b>25</b>	<b>Hook</b>	
<b>26</b>	<b>Hook base</b>	
<b>27</b>	<b>Spring</b>	HORWIN0280
<b>28</b>	<b>Hook axis</b>	
<b>29</b>	<b>Left edge trim BLACK</b>	HORWIN0025
	<b>Left edge trim BLUE</b>	
	<b>Left edge trim ORANGE</b>	
	<b>Left edge trim WHITE</b>	
<b>30</b>	<b>Right edge BLACK</b>	HORWIN0294
	<b>Right edge BLUE</b>	
	<b>Right edge ORANGE</b>	
	<b>Right edge WHITE</b>	
<b>31</b>	<b>Insert self tapping screw 5mm</b>	
<b>32</b>	<b>BOSS self tapping screw 4mm</b>	HORWIN0203


## TRIM PARTS 2



N°	PIÈCE	RÉFÉRENCE
1	Front cover	HORWIN0295
2	Vehicule body charging port	HORWIN0296
3	Controller cover	HORWIN0297
4	Left side cover decorative cover	HORWIN0298
5	Right side cover decorative cover	HORWIN0299
6	Left side light	HORWIN0300
7	Right side light	HORWIN0301
8	Left side cover BLACK	HORWIN0302
	Left side cover BLUE	


<b>N°</b>	<b>PIÈCE</b>	<b>RÉFÉRENCE</b>
	Left side cover ORANGE	
	Left side cover WHITE	
9	Right side cover BLACK	HORWIN0303
	Right side cover BLUE	
	Right side cover ORANGE	
	Right side cover WHITE	
10	Left side cover lining	HORWIN0304
11	Right side cover lining	HORWIN0305
12	Insert M6	HORWIN0306
13	Convertor 4 cables with the time delay	HORWIN0307
14	Converter holder	HORWIN0308
15	Taillight BLACK	HORWIN0309
	Taillight BLUE	
	Taillight ORANGE	
	Taillight WHITE	
16	Taillight	HORWIN0310
17	Insert	
18	Seat bucket inner lid	HORWIN0316
19	Power switch cover	HORWIN0315
20	Seat bucket	HORWIN0314
21	Rear handrest steel	HORWIN0313
22	Inner baffle	HORWIN0312
23	Wrapped tail	HORWIN0311
24	Boss self tapping screw 4mm	HORWIN0203
25	Insert self tapping screw 5mm	

# BENCH




N°	PIÈCE	RÉFÉRENCE
1	Seat cushion assembly	HORWIN0317
2	Seat cushion bottom plate	
3	Seat back	
4	Hinge	HORWIN0318

# CONTROLLER BATTERY




N°	PIÈCE	RÉFÉRENCE
1	CONTROLLER EK1	HORWIN0319
2	MAIN DISTRIBUTION CABLE EK1	HORWIN0320
3	POWER SUPPLY CONNECTOR CABLE	HORWIN0321
4	BATTERY 72V/26AH	HORWIN0322
5	CHARGER 5A EK1	HORWIN0008

## BACK SHOCK ABSORBERS




N°	PIÈCE	RÉFÉRENCE
1	REAR FORT EK1	HORWIN0324
2	REAR FORK BOLT AND NUT	HORWIN0325
3	REAR SHOCK ABSORBER	HORWIN0326
4	MOTOR AXLE RETAINER COMPL.	HORWIN0327
5	LEFT FORK GUARD PLATE	HORWIN0328
6	RIGHT FORK GUARD PLATE	HORWIN0329
7	LEFT FORK GUARD PLATE DECORATIVE COVER	HORWIN0330
8	RIGHT FORK GUARD PLATE DECORATIVE COVER	HORWIN0331

# BACK FENDER



N°	PIÈCE	RÉFÉRENCE
1	REAR MUDGUARD BRACKET	HORWIN0332
2	REAR FENDER	HORWIN0333
3	LICENSE PLATE LAMP UPPER COVER	HORWIN0334
4	LICENSE PLATE LAMP LOWER COVER	HORWIN0335
5	REAR LICENSE PLATE LIGHT	HORWIN0336
6	REAR REFLECTOR	HORWIN0337
7	REAR LICENSE PLATE-REAR SIDE REFLECTOR BRACKET	HORWIN0338
8	REAR REFLECTOR	HORWIN0340
9	RUBBER GASKET	HORWIN0339


# LABEL



N°	PIÈCE	RÉFÉRENCE
1	SIDE STICKER EK1	HORWIN0341
2	NAMEPLATE	HORWIN0342
3	HIGH VOLTAGE WARNING STICKER	HORWIN0343
4	LEFT SIDE COVER BLACK	
	LEFT SIDE COVER BLUE	
	LEFT SIDE COVER ORANGE	
	LEFT SIDE COVER WHITE	



# EK 1 DS



N°	PIÈCE	RÉFÉRENCE
1	SINGLE SEAT CUSHION ASSEMBLY	
2	REAR RACK	
3	RACK BASE	
4	LEFT AND RIGHT RACKS	



EK1	EK3
Démontage du phare avant	Démontage du phare avant
Démontage du panneau de bord	Démontage du panneau de bord
Démontage du panneau latéral	Démontage du moteur
Démontage du port usb de recharge	Démontage du convertisseur d'accélération et alarme
Démontage du cache décoratif de la fourche arrière	Démontage du port USB de recharge
Démontage du siège et colonne de direction	Démontage du phare avant
Démontage du cache avant bas	Démontage du panneau d'instruments
Démontage cache fond plat	Démontage du bloc phare déjà retiré
Démontage repose-pieds	Démontage serrure
Remplacer le convertisseur DC avant	Démontage clignotants
Démonter le garde-boue arrière	Démontage coffre et siège
Démontage de la suspension arrière	Démonter le contrôleur
Chemin de câblage	Démonter le convertisseur DC
Remplacement levier de frein	Démonter la bordure latérale
Remplacer le bloc frein avant	Démontage accoudoir et façade
Démontage du clignotant	Démontage des caches latéraux et cache feu arrière
Démontage du convertisseur d'accélération	Démontage du coffre avant
Démontage de la serrure et du DC arrière	Démontage du panneau décoratif de la fourche arrière
Démontage du coffre avant et repose pieds	Démontage du frein
Démontage du moteur dans le moyeu arrière	Démontage de la chaîne
Retrait des caches latéraux et du cache du feu arrière	Pose pare-brise
Pose pare-brise	